



Replacing Nokia Classic 2600c-2b Faceplate

Replacing the faceplate of the Nokia Classic phone

Written By: Ian VanZandt






TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Faceplate



- Press down on the button located at the bottom of the phone, using the center ridge as a guide.
- Pull the phone apart from the bottom, keeping the button pressed down.

 **CAUTION!** The plastic opening tool may be used to gain leverage. Some force is required to open.

Step 2




- Remove the back cover to expose the battery.

Step 3




- Place a finger or plastic opening tool in the gap between the battery and the phone.
- Gently lift the battery out.

Step 4



- Locate the plastic latches on the left and right sides of the phone.
- Insert the plastic opening tool or a fingernail into each latch and pry them open individually.

 CAUTION! Some force is required.

Step 5



- Remove the faceplate with the number pad attached.

Step 6



- Turn the faceplate so the number pad faces downward.
- Lift the number pad out of the faceplate.
- Apply new faceplate.
- Follow the instructions in reverse order to reassemble the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-29 08:07:05 AM.